

Chapter 14: Analyses of variance: Going beyond *t*-tests

TXCL7565/PHSC7565

What This Chapter Covers

- Factors and levels
- One-way analysis of variance
- Two-way analysis of variance
- Fixed and random factors

When we want to compare interval scale data between more than 2 groups, we use an **Analysis of Variance (ANOVA)**.

FACTORS AND LEVELS

Factors and levels

- **Factor** - something that can take two or more categorical values.
 - either spontaneously varies or can be manipulated as part of an experiment
 - want to know if the different values of the factor cause different values of the outcome
- **Level** - individual values of a factor

Sex is a factor.

‘Male’ and ‘female’ are values of that factor.

ONE-WAY ANALYSIS OF VARIANCE

One-way ANOVA

One-way ANOVA - the independent (predictor) variable is single experimental factor with multiple levels and the dependent (outcome) variable is an interval variable

Table 14.1 Effect catalyst on yield (percentage of theoretical maximum)

Platinum	Palladium	Iridium	Palladium/ Iridium	Rhodium
11.3	15.4	12.1	13.1	12.0
10.7	17.0	12.2	13.7	11.6
9.8	18.4	13.1	13.5	9.1
10.4	17.5	11.8	14.0	11.9
11.5	18.8	10.4	14.2	11.3

Multiple *t*-tests. vs ANOVA

Could do several *t*-tests for all the comparisons that we are interested in...

- Multiple testing
 - For each comparison there is a 5% risk of a false positive. If there are 5 comparisons, the risk of at least one producing a significant results when none are truly different is ...

- (probability of not making a mistake)⁵


$$1 - (1 - \alpha)^5 = 1 - 0.95^5 = 0.23$$

- Estimate of SD
 - In *t*-test, estimating within group SD from 10 samples. In ANOVA estimating within group SD from 25 samples.

Two-sample t-test vs. One-way ANOVA

- ***Two sample t-test*** - Is the difference between these two samples means greater than can reasonably be accounted for by random sampling error?
- ***One-way ANOVA*** - Are the differences among these various sample means greater than can reasonably be accounted for by random sampling error?

Diagrammatic representation of one-way ANOVA





Null and alternative hypothesis

- ***Null hypothesis*** - the population means for all levels of the factor are the same
- ***Alternative hypothesis*** - at least one of the population means for a level of the factor is different from the rest of the population means for the remaining factors


$$H_0 : \mu_1 = \mu_2 = \cdots = \mu_n$$

H_a : at least one μ is different from the rest


Intra-group variation - variation within a group of replicates
Inter-group variation - variation between groups



What governs whether a significant result will emerge?



1. Select 'One-way ANOVA' from Column analyses



2. Click OK

1. Select 'No matching or pairing' and 'Yes. Use ANOVA'

Parameters: One-Way ANOVA (and Nonparametric)

Experimental Design Multiple Comparisons Options

Experimental design

☒ No matching or pairing

☐ Each row represents matched, or repeated measures, data

	Group A	Group B	Group C	Group D
	Data Set-A	Data Set-B	Data Set-C	Title
	Y	Y	Y	Y
1				
2				
3				

Assume Gaussian distribution?

☒ Yes. Use ANOVA.

☐ No. Use nonparametric test.

Assume sphericity (equal variability of differences)?

☒ No. Use the Geisser-Greenhouse correction. Recommended.

☐ Yes. No correction. Results will match prior versions of Prism.

Based on your choices (on all three tabs), Prism will perform:

- Ordinary one-way ANOVA.

Cancel OK

2. Click OK

File

Sheet

Undo

Clipboard

Analysis

Interpret

Change

Draw

Write

Text

Export

Print

Send

File icons

Sheet icons

Undo icons

Clipboard icons

Analysis icons

Interpret icons

Change icons

Draw icons

Write icons

Text icons

Export icons

Print icons

Send icons

11

Arial

A

A

B

I

U

x²

x₂

Text formatting icons

Family

Search results

Data Tables

catalyst

Info

Project info 1

Results

Ordinary one-way ANOVA

Graphs

catalyst

Layouts

Ordinary one-way ANOVA						
18	Bartlett's statistic (corrected)	4.973				
19	P value	0.2901				
20	P value summary	ns				
21	Are SDs significantly different (P < 0.05)?	No				
22						
23	ANOVA table	SS	DF	MS	F (DFn, DFd)	P value
24	Treatment (between columns)	148.1	4	37.02	F (4, 20) = 38.37	P<0.0001
25	Residual (within columns)	19.3	20	0.9648		
26	Total	167.4	24			
27						
28	Data summary					
29	Number of treatments (columns)	5				
30	Number of values (total)	25				
31						
32						
33						
34						
35						
36						

Ordinary one-way ANOVA of catalyst

ANOVA

ANOVA Table

ANOVA Table	SS	DF	MS	F (DFn, DFd)	P value
Treatment (between columns)	148.1	4	37.02	F (4,20) = 38.37	<0.0001
Residual (within columns)	19.3	20	0.9648		
Total	167.4	24			

Follow up tests - Interpreting significance

- $p\text{-value} < 0.05$ indicates that we have evidence against the null hypothesis
- don't know the nature of the differences


FOLLOW-UP TESTS

Dunnett's test

- Select one treatment as a 'control' or 'reference' group. All other groups are then compared against the control.
- Confidence intervals and p-values are automatically adjusted to control 'test-wide error rate' to 5%

1. Select the
'Multiple
Comparisons'
tab

2. Select the
'Compare the
mean of each
column with
the mean of a
control
column'



1. Select the
'Options' tab

2. Select
'Dunnett' for
multiple
comparisons
test

3. Swap
direction of
comparison
to match
Table 14.5
results

Parameters: One-Way ANOVA (and Nonparametric)

Experimental Design Multiple Comparison **Options**

Multiple comparisons test

- ☒ Correct for multiple comparisons using statistical hypothesis testing. Recommended.
Test: **Dunnett (recommended)**
- ☐ Correct for multiple comparisons by controlling the False Discovery Rate.
Test: Two-stage step-up method of Benjamini, Krieger and Yekutieli (recommended)
- ☐ Don't correct for multiple comparisons. Each comparison stands alone.
Test: Fisher's LSD test

Multiple comparisons

- ☒ **Swap direction of comparisons (A-B) vs. (B-A)**
- ☒ Report multiplicity adjusted P value for each comparison.
Each P value is adjusted to account for multiple comparisons.

Family-wise significance and confidence level: 0.05 (95% confidence interval)

Graphing

- ☐ Graph confidence intervals.
- ☐ Graph residuals.
- ☐ Graph ranks (nonparametric).
- ☐ Graph differences (repeated measures).

Additional results

- ☐ Descriptive statistics for each data set.
- ☐ Report comparison of models using AICc.


Output

P-value style: GP: 0.1234 (ns), 0.0332 (*), 0.0021 (**), 0.0002 (***), <0.0...

Show **4** significant digits.

☐ Make options on this tab be the default for future One-Way ANOVAs.

Cancel OK




Tukey's test

- All pairwise comparisons between levels are made.
- Confidence intervals and p-values are automatically adjusted to control 'test-wide error rate' to 5%

1. Select the
'Multiple
Comparisons'
tab

2. Select the
'Compare the
mean of each
column with
the mean of
every other
column'



1. Select 'Tukey'
for type of
Multiple
comparisons
test

Parameters: One-Way ANOVA (and Nonparametric)

Experimental Design Multiple Comparisons Options

Multiple comparisons test

☒ Correct for multiple comparisons using statistical hypothesis testing. Recommended.
Test: **Tukey (recommended)**

☐ Correct for multiple comparisons by controlling the False Discovery Rate.
Test: Two-stage step-up method of Benjamini, Krieger and Yekutieli (recommended)

☐ Don't correct for multiple comparisons. Each comparison stands alone.
Test: Fisher's LSD test

Multiple comparisons

☐ Swap direction of comparisons (A-B) vs. (B-A).
☒ Report multiplicity adjusted P value for each comparison.
Each P value is adjusted to account for multiple comparisons.

Family-wise significance and confidence level: 0.05 (95% confidence interval)

Graphing

☐ Graph confidence intervals.
☐ Graph residuals.
☐ Graph ranks (nonparametric).
☐ Graph differences (repeated measures).

Additional results

☐ Descriptive statistics for each data set.
☐ Report comparison of models using AICc.


Output

P-value style: GP: 0.1234 (ns), 0.0332 (*), 0.0021 (**), 0.0002 (***), <0.0...

Show 4 significant digits.

☐ Make options on this tab be the default for future One-Way ANOVAs.

Cancel OK



Balanced data

- **Balanced data** - the same number of sample in each group
- The power of the ANOVA will be greatest with a balanced data set
- The power for Tukey's tests will be greatest with a balanced data set.
- The only circumstance where power will be greater with an imbalanced data set is where a Dunnett's test is planned (more samples in 'control' group = more power).


Requirements for performing analysis of variance

- Randomly sampled from a population
- Normally distributed values within a level
- Equal SD in each group

Assumption of equal SD

- Brown-Forsythe Test - statistical test for differences in SD between groups
 - $p < 0.05$ indicates the intra-group variances are significantly different
- Bartlett's Test - statistical test for differences in SD between groups; sensitive to non-normality
 - $p < 0.05$ indicates the intra-group variances are significantly different and/or data are NOT normally distributed

Common graphics for ANOVA




TWO-WAY ANALYSIS OF VARIANCE

Investigating two experimental factors simultaneously

Two-way analysis of variance is used when:

- The endpoint is a measured value (generally on the interval scale)
- There are two experimental factors
- All possible combinations of the two factors have been studied (full factorial experiment)

Diagrammatic representation of two-way ANOVA




1. Select 'Grouped' for new table.

New Data Table and Graph

Grouped tables have two grouping variables, one defined by columns and the other defined by rows

Table format:		A			B		
		Control			Treated		
		A:Y1	A:Y2	A:Y3	B:Y1	B:Y2	B:Y3
1	Male						
2	Female						



[? Learn more](#)

Enter/import data:

- ☐ Enter and plot a single Y value for each point
- ☒ Enter replicate values in side-by-side subcolumns
- ☐ Enter and plot error values already calculated elsewhere

Enter:

Use tutorial data:

- ☐ Two-way ANOVA - Ordinary - two data sets
- ☐ Two-way ANOVA - Ordinary - three data sets
- ☐ RM two-way ANOVA - matched values stacked
- ☐ RM two-way ANOVA - matched values in same row
- ☐ Three-way ANOVA 2 x 2 x 2
- ☐ Multiple t tests
- ☐ Heat map
- ☐ More tutorial data...

Cancel Create

2. Select 'Enter replicate values in side-by-side subcolumns' with the maximum number of samples per group.

GraphPad PRISM

catalyst — Edited

File Sheet Undo Clipboard Analysis Change Import Draw Write Text Export Print Send LA Help

Table format: Grouped

		Group A					Group B					
		platinum					palladium					
		A:Y1	A:Y2	A:Y3	A:Y4	A:Y5	B:Y1	B:Y2	B:Y3	B:Y4	B:Y5	C:Y1
1	stirred	11.1	11.7	9.8	12.1	9.3	15.9	18.9	18.9	15.5	17.2	10.9
2	ultrasonic	12.8	13.8	12.3	12.4	12.0	20.0	19.9	19.5	20.5	18.3	14.8
3	Title											
4	Title											
5	Title											
6	Title											
7	Title											
8	Title											
9	Title											
10	Title											
11	Title											
12	Title											
13	Title											
14	Title											

Family Search results Data Tables catalyst catalyst and mixing Info Project info 1 Results Ordinary one-way ANOVA ANOVA Multiple comparisons Ordinary one-way ANOVA ANOVA Multiple comparisons Graphs catalyst catalyst and mixing Data 3 Layouts

catalyst and mixing Row 2, Column F





Table 14.8 Mean yield for each combination of catalyst and stirring method (%)


	Pt	Pd	IR	Pd/Ir	Rh
Stirred	10.80	17.28	11.58	13.94	11.36
Ultrasonic	12.66	19.64	14.30	16.32	13.34

Interactions

Interaction is present when the effect produced by changing the level of one factor is dependent upon the level of another factor.



Parallel lines =
No interaction



Non-parallel lines =
Interaction present


Null hypotheses

In this case, we will be testing three null hypotheses:

1. Population means among the levels of the first factors are the same
2. Population means among the levels of the second factors are the same
3. There is not interaction between the two factors

These are independent hypotheses. We could end up accepting them all, rejecting them all, or accepting some and rejecting others.

1. Select 'Two-way ANOVA' from Grouped analyses



1. Select 'No matching' under Experimental design

2. Can change Factor names

Parameters: Two-Way ANOVA

Experimental Design Multiple Comparisons Options

Experimental design

☒ No matching. Use regular two-way ANOVA (not repeated measures).

☐ Each column represents a different time point, so matched values are spread across a row.

☐ Each row represents a different time point, so matched values are stacked into a subcolumn.

☐ Repeated measures by both factors.

Table format:		Group A		Group B		Group C	
Grouped		Title		Title		Title	
		A:Y1	A:Y2	B:Y1	B:Y2	C:Y1	C:Y2
1	Title						
2	Title						
3	Title						
4	Title						

Factor names

Name the factor that defines the columns: Catalyst


Name the factor that defines the rows: Mixing

Based on your choices (on all three tabs), Prism will perform:

- Ordinary two-way ANOVA

Cancel OK

2. Click OK



ANOVA table	SS	DF	MS	F (DFn, DFd)	P value
Interaction	1.186	4	0.2965	F (4, 40) = 0.2657	P=0.8983
Mixing	63.85	1	63.85	F (1, 40) = 57.2	P<0.0001
Catalyst	300.9	4	75.23	F (4, 40) = 67.41	P<0.0001
Residual	44.64	40	1.116		

Interpretation of two-way ANOVA in the absence of interaction

- P-value for interaction effect = 0.898, non-significant interaction effect
- Since catalyst and mixing are significant but the interaction is not, there are 'additive' effects of catalyst and mixing


Estimating the effect of type of mixing

Metal	Increase in yield (%)
Pt	1.86
Pd	2.36
Ir	2.72
Pd/Ir	2.38
Rh	1.98
MEAN	2.26%

Summary of example two-way ANOVA

- There is no significant evidence of interaction between the two factors ($p=0.898$).
- There is significant evidence that yield varies according to the mixing method used ($p<0.001$).
Whatever metal is used, ultrasonic mixing produces a yield around 2.3% greater than that achieved by stirring.
- There is significant evidence confirming that yield varies according to which catalyst is used ($p<0.001$).

Two-way ANOVA with Interaction



Summary of example two-way ANOVA with interaction

ANOVA table	SS	DF	MS	F (DFn, DFd)	P value
Interaction	32.29	2	16.14	F (2, 30) = 20.35	P<0.0001
Force	58.85	1	58.85	F (1, 30) = 74.21	P<0.0001
Punch	203.4	2	101.7	F (2, 30) = 128.2	P<0.0001
Residual	23.79	30	0.7931		

- There is significant evidence of interaction between the two factors ($p<0.0001$).
- This is an example of quantitative interaction and should be followed up by specific comparisons.

What did we learn?

- One-way ANOVA is used when there are more than two groups to compare based on an interval outcome.
- When looking at pairwise comparisons of levels in a significant ANOVA model, you must 'adjust' your p-values for multiple testing, e.g., Tukey, Dunnett.
- Two-way ANOVA is used when there are two nominal/ordinal factors that contribute to an interval outcome and all possible combinations of the two factors have been studied
- A significant interaction in a two-way ANOVA need to be interpreted with caution (graphics are extremely helpful).